


# Connecting the NetMedia CTVS S-Video Cable



1. Insert one S-Video connector into the S-Video OUT jack of the Video Source (DSS, VCR, A/V Receiver, etc.).
2. Insert the male RCA connector from the Video Source into the Caller-TV VIDEO IN jack.
3. Insert the other S-Video connector into the S-Video IN jack of the Video Display device (Television, A/V Receiver, etc.).
4. Insert the male RCA connector from the Video Display device into the Caller-TV VIDEO OUT jack.

Connect audio cables directly from Video Source AUDIO OUT jacks to Video Display device AUDIO IN jacks.  
Insert phone cable from a telephone connection (with Caller-ID service activated) into the Caller-TV LINE jack.  
Plug the Caller-TV's 12V DC, 100mA power supply into a properly grounded power source and the Caller-TV 12VDC jack.

See the Caller-TV manual for more information regarding Caller-TV and other installation configurations.



NetMedia, Inc.  
10940 N. Stallard Place, Tucson, Arizona 85737  
(520) 544-4567 Fax: (520) 544-0800  
info@netmedia.com www.netmedia.com